



# A Pak for all reasons.

Cummins powerpacks.

CustomPak.



ComPak.



FirePak.



Designed in  
Australia.

Built in  
Australia.

For Australian  
conditions.

# ComPak.

The compact alternative.

Designed to suit those applications where space is at a premium.

QUANTUM full electronic Tier 3 stage IIIa emissions certified range covering 65 hp to 260 hp.

All Cummins ComPak models utilise the following:

- Heavy duty industrial cooling packages rated to operate continuously in ambient temperature in excess of 50 degree Celsius
- Pedestal mounting legs
- Heavy duty dual element air cleaners with restriction indicators
- Industrial mufflers
- Basic - start /stop, RPM, engine protection & operating hours
  - Alternative engine control panels available upon request
- All Cummins ComPak components are covered by the same industrial warranty as the base engine



B3.3T3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	65 - 85	56 - 63	2600



QSB3.3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	80 - 99	60 - 74	2600



QSB4.5

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	110 - 160	82 - 119	2200



QSB6.7

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	133 - 260	99 - 194	2500

## Warranty Coverage.



Cummins base engine coverage is two years or 2,000 hours of operation, or one year/unlimited hours of operation, whichever comes first. It covers:

- Full parts and labour on warrantable failures.
- Consumables not reusable due to warrantable failures.

Extended Major Components coverage is three years or 10,000 hours of operation, whichever occurs first from the delivery date, and becomes active at the expiry of the base engine warranty. It covers:

- Warrantable failures of covered components. Bushing and bearing failures not included.

Package Units – CPAK – FPAK - COMPAK

When a product is defined as a Package Unit, all components of the product which were purchased from Cummins South Pacific as a packaged product have the same Base Engine Warranty coverage as the engine.

Package units built by Cummins South Pacific when the following components, as a minimum, are purchased from Cummins:

- Engine ■ Pedestal Feet ■ Cooling packages ■ Fan

Conditions apply. Full warranty details can be found in the Industrial Cummins Warranty brochure (Bulletin 3381322).

Warrantable failures includes defect in material or factory workmanship. Covered components includes engine cylinder block, camshaft, crankshaft and connecting rods.

# CustomPak.

Modular design enables you to select the matched power pack components to suit your application.

Choose from:

QUANTUM full electronic Tier 3 stage IIIa emissions certified range covering 65 hp to 950 hp.

Mechanical range covering 100 hp to 260 hp.

All Cummins CustomPak models utilise the following:

- Heavy duty industrial cooling packages rated to operate continuously in ambient temperature in excess of 50 degree Celsius
- Heavy section structural steel base rails
- Heavy duty dual element air cleaners with restriction indicators
- Industrial mufflers
- Three levels of engine control panels to protect your investment in all applications
  - Basic - start/stop, RPM, engine protection & operating hours
  - Intermediate – basic plus diagnostics and pump protection
  - Premium – intermediate plus additional OEM inputs for equipment protection, auto/remote start and monitoring
- All Cummins CustomPak components are covered by the same industrial warranty as the base engine



B3.3T3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	65 - 85	56 - 63	2600



QSB3.3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	80 - 99	60 - 74	2600



QSB4.5

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	110 - 160	82 - 119	2500



QSB6.7

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	133 - 260	99 - 194	2500



QSCT3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
	205 - 305	152 - 227	2200 2600



QSL9

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	280 - 325	209 - 242	2100

# CustomPak.



QSMT3

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	300 - 400	224 - 298	2100



QSX530

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	375 - 530	279 - 395	2100



QSX600

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	560 - 600	418 - 447	2100



QSK19

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T3	506 - 700	377 - 522	2000



QSK23

EMISSIONS LEVEL	RANGE (HP)	RANGE (kW)	RPM
T1	760 - 950	567 - 708	2100



6BTA-152

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	152	113	2500



6BTA-177

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	177	132	2500



6CTA-260

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	260	194	2200

# FirePak.

Designed specifically to meet the requirements of the Australia, New Zealand and the South Pacific fire protection industry. Mechanical range covering 100 hp to 260 hp.

All Cummins FirePak models utilise the following:

- Fully compliant with Australian standard AS2941 & New Zealand standard NZS4541/2007
- Pedestal mounting legs
- Industrial air cleaner
- Industrial grade copper tube heat exchangers with belt and alternator guarding
- 90 degree exhaust elbows
- Throttle adjustment and lock
- All Cummins FirePak components are covered by the same industrial warranty as the base engine



4BTA-100

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	100	74	2500



4BTA-130

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	130	97	2500



6BTA-152

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	152	113	2500



6BTA-177

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	177	132	2500



6CTA

EMISSIONS LEVEL	HP	RANGE (kW)	RPM
T2	260	193	2200



**Customer support -  
Every place you need it.**

Cummins has the most comprehensive service support network in the South Pacific with 41 company-owned branches, more than 170 dealers, and over 240 field service vehicles.

In addition, customers in Australia and New Zealand can call the Australian-based Cummins Support Centre any time of the day, any day of the year, for breakdown assistance or technical advice. All you need to do is ring a single number – 1300 CUMMINS (if you're in Australia) or 0800 CUMMINS (if you're in New Zealand) – and you can speak directly to a highly experienced Cummins service technician.

With Cummins you're not just buying an engine, you're buying a partnership with all the support, services and parts you need.



**The Cummins Support Centre boasts a team of highly experienced service technicians who are based at a dedicated facility in Melbourne.**

# Everywhere. Cummins locations.

**AUSTRALIA**

**New South Wales**

Dubbo	02 6881 8260
Grafton	02 6641 1000
Leeton	02 6953 3077
Muswellbrook	02 6541 0611
Newcastle	02 4964 8466
Orange	02 6360 2777
Queanbeyan	02 6297 3433
Sydney	02 9616 5300
Tamworth	02 6765 5455
Wollongong	02 4227 2444

**Tasmania**

Devonport	03 6424 8800
Hobart	03 6262 5700

**Victoria**

Campbellfield	03 9357 9200
Laverton	03 8368 0800
Mildura	03 5022 0800
Pakenham	03 5943 3700
Swan Hill	03 5033 1511
Wodonga	02 6024 3655

**Northern Territory**

Darwin	08 8947 0766
--------	--------------

**Western Australia**

Bunbury	08 9725 6777
Geraldton	08 9964 5449
Kalgoorlie	08 9080 1300
Karratha	08 9144 4646
Perth	08 9475 8777

**Queensland**

Brisbane	07 3710 4700
Cairns	07 4035 2999
Cloncurry	07 4742 0088
Emerald	07 4983 9000
Mackay	07 4952 8100
Toowoomba	07 4633 7627
Townsville	07 4774 7733

**NEW ZEALAND**

Auckland	09 277 1000
Bay Of Plenty	07 345 6699
Palmerston Nth	06 356 2209
Whangarei	09 438 8892

**South Australia**

Adelaide	08 8368 4300
Mount Gambier	08 8725 6422
Port Lincoln	08 8683 1967

**PAPUA NEW GUINEA**

Lae	05 472 3699
Port Moresby	05 323 2471

**BRANCH/DEALER STAMP**



For Australia

**1300Cummins**  
Ph 1300 286 646

For New Zealand

**0800Cummins**  
Ph 0800 286 646



Cummins Head Office  
2 Caribbean Drive  
Scoresby Vic 3179 Australia  
Phone 613 9765 3222  
Fax 613 9763 0079  
[www.southpacific.cummins.com](http://www.southpacific.cummins.com)